



L
PER ACCORCIARE IL PULSANTE D'EMERGENZA:
TAGLIARE DELLA STESSA MISURA "X" I TRE ELEMENTI A, B, C.
POUR COUPER LE BOUTON D'URGENCE, REDUIRE DE LA MEME MESURE X LES TROIS ELEMENTS A, B, C.

L = 840 mm. - Mini = 330 mm.

L = 840 mm. - L.Minima = 330 mm.

